

WuduMate Compact (Porcelain) - Installation Guide

Locate WuduMate Porcelain Fixing Kit



- Place the WuduMate into its intended fixing position
- Mark the position of the WuduMate on the floor together with the locations of the fixing holes in the sides of the unit
- Remove the WuduMate
- Secure the multi-position fixing kits to the floor with appropriate floor fixings either side of the unit to line up with the inside wall of WuduMate when placed into position.
- Install the faucet/tap and TMV if being used; there is space in the back of the WuduMate for the TMV; (flex pipes are provided with the WuduMate Manual Lever Pillar tap/faucet)
- If installing a WuduMate Pillar tap with ½"BSP connection, there is a converter to North American standard of ¾" NPS available from WuduMate
- Install waste/trap in the WuduMate and connect to mains drainage system (Suggested plumbing tip - raise the unit 100mm on blocks to make connections)
- When the waste/drain is installed in the WuduMate, the direction of the outlet is towards the back of the unit, but this could be turned with a 90 degree bend down through the floor to be picked up perhaps in the ceiling void below.



Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK Trading as WuduMate $^{\circledR}$

Tel: +44 (0) 1784 748080 info@wudumate.com | www.wudumate.com



- Lift the WuduMate into position and secure, screwing through the holes into the multi-position fixing kits, inserting screw end covers when complete
- Seal around the WuduMate with silicone sealant (depends on wall and floor surface)
- Polish with a non-abrasive cloth

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK Trading as WuduMate $^{@}$

Tel: +44 (0) 1784 748080 info@wudumate.com | www.wudumate.com