

# WuduMate-R



## WuduMate-R Fitting Instructions

1. Place the WuduMate-R into intended fixing position.
2. Mark the position of the WuduMate-R on the floor together with the locations of the fixing holes in the sides of the unit.
3. Remove the WuduMate-R.
4. Secure the multi-position fixing kits to the floor with appropriate floor fixings either side of the unit to line up with the inside wall of WuduMate-R unit when placed into position.
5. Install tap and water supply, suggest using flexible hosing to assist in installation.
6. Install trap and waste in the WuduMate-R and connect to mains drainage system, suggest using flexible piping to assist installation.
7. Lift the WuduMate-R into position and secure, screwing through the holes into the multi-position fixing kits, inserting screw end covers when complete.
8. Optionally, seal around the WuduMate-R base with silicone sealant (depending on floor surface).
9. Optionally, tile around the back and sides of the WuduMate-R and seal.
10. Polish with a soft cloth.

Specialist Washing Co.

