



WuduMate Classic - Installation Guide

- Mark the location of the fixing brackets on the outside edge of the WuduMate
- **Remove the protective trim from bottom edge of unit**
- Place the WuduMate on the floor in its intended final position (ensure the open back of the unit is positioned against the wall)
- Mark the position of the WuduMate on the floor and wall, together with the locations of the fixing brackets, as indicated by the marks you have made on the outside of the WuduMate
- Remove the WuduMate
- Measure the distance of the fixing brackets from the:
 - outside of the unit
 - cut outs on back fixing bar
 - “hole centre” in back fixing
- Transcribe these measurements onto the wall and floor
- Drill and fix supplied fixings into the wall and floor with suitable wall and floor fixings
- Install tap and water supply; suggest using flexi-pipes (provided only with a manual lever pillar tap)
- Install waste/trap in the WuduMate and connect to mains drainage system (*plumbers trick suggested is to raise the unit 100mm on blocks to make connections*)
- Lift the WuduMate to a horizontal position, push against the wall to locate wall fixings onto the bracket on the wall end of the WuduMate, and lower gently to locate floor fixing firmly on the floor
- Seal around the WuduMate with silicone sealant (depends on floor surface)
- Polish with a non-abrasive cloth

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748080
info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK