



WuduMate Classic - Installation Guide

- Locate WuduMate Classic Fixing Kit:



- Mark the location of the fixing bracket which runs across the back of the WuduMate on the outside edge of the WuduMate



Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748080
info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK

WuduMate®



- Remove the protective trim from bottom edge of the WuduMate



REMOVE
PROTECTIVE
TRIM



SEAL TO
FLOOR WITH
SILICONE

- Place the WuduMate on the floor in its intended final position (ensure the open back of the unit is positioned against the wall)
- Mark the position of the WuduMate on the floor
- Mark the position of the WuduMate fixing bracket which runs across the back of the WuduMate (as indicated by the marks you have made on the outside of the WuduMate)
- Remove the WuduMate
- Measure the distance of the fixing brackets from the:
 - outside of the unit
 - cut outs on back fixing bar
 - 'hole centre' in back fixing
- Transcribe these measurements onto the wall and floor
- Drill and fix supplied fixings into the wall and floor with suitable wall and floor fixings

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748080

info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK

WuduMate®



- Install tap and water supply; suggest using flexi-pipes (provided only with a manual lever pillar tap)

Install waste/trap in the WuduMate and connect to mains drainage system

Plumbing tip 2 - raise the unit 100mm on blocks in order to make the drainage connections

- Lift the WuduMate to a horizontal position, push against the wall to locate wall fixings onto the bracket on the wall end of the WuduMate, and lower gently to locate floor fixing firmly on the floor

Plumbing Tip 2 – Install the plumbing with pipe not flexi, leaving the drain in exactly the right position to receive the WuduMate, but with the top half of the drain left off. Lower the WuduMate carefully into position, so the bottom of the drain can be seen through the drain hole, and finally screw in the top half of the drain,

- Seal around the WuduMate with silicone sealant (depends on wall and floor surface)
- Polish with a non-abrasive cloth
- If installing more than one WuduMate Classic in a series, it's suggested to leave a gap of minimum of circa 150mm to 200mm (6" to 8") between units and between outer units and any walls, to assist in cleaning
- Please refer WuduMate Cleaning and Aftercare recommendations

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748080

info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK