

WuduMate



WuduMate Compact (Acrylic) - Installation Guide

- Locate WuduMate Compact Fixing Kit: -



- The height of the fixing bracket which runs across the back of the unit is 300mm from the floor to the bottom of the bar, and the bar is 45mm thick. Mark the required position of the bracket supplied, so that it can receive the bracket at the rear of the unit.
- Drill and fix the bracket onto the wall with suitable wall fixings
- Install the faucet/tap and TMV if being used; there is space in the back of the WuduMate for the TMV; (flex pipes are provided with the WuduMate Manual Lever Pillar tap/faucet)
- If installing a WuduMate Pillar tap with 1/2" BSP connection, there is a converter to North American standard of 3/4" NPS available from WuduMate
- Install the waste/drain in the WuduMate and connect to mains drainage system
(Suggested plumbing tip - raise the unit 100mm on blocks to make connections)
- When the waste/drain is installed in the WuduMate, the direction of the outlet is towards the back of the unit, but this could be turned with a 90 degree bend down through the floor to be picked up perhaps in the ceiling void below.

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748 080
info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK

WuduMate



Lift the WuduMate and push against the wall to locate the bracket on the WuduMate into the fixings, and lower gently into position on the floor

- Seal around the WuduMate with silicone sealant (depending on wall and floor surface)
- Polish with a non-abrasive cloth and keep clean with non-abrasive household cleaning materials

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748 080
info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK