

WuduMate®



WuduMate Modular After Care

The WuduMate Modular

The Wudumate Modular is manufactured from high quality, sanitary-grade acrylic, and should be cleaned and maintained in the same way as similar acrylic items found in the home, such as shower trays.

In the same way that a shower tray can be expected to last 'as new' for many years, so can the WuduMate Modular, provided regular cleaning with the appropriate materials is undertaken.

Cleaning should be undertaken with a normal, NON-SCOURING (i.e non-abrasive) household, cleaning agent or detergent and a soft sponge or cloth. (e.g *Daily Cleaner* from the *WuduClean* range.)

Seat Poles and Taps

In areas of hard water, limescale can accumulate on the stainless steel seat pole and base (base is protected if seat pole base cover used), but can easily be removed by using a normal NON-SCOURING household limescale remover. (e.g. *Limescale Remover* from the *WuduClean* range).

Drains

The WuduMate Modular drain should be treated periodically with a normal, household drain cleaner. (*WuduClean Enzyme Drain Cleaner* is especially good, being specifically designed to combat the unusual mix of high body fat and hair, typically found in ablution areas, where generally little detergent is used.)

Silicone

As with shower trays at home, silicone can sometimes gather mould, mostly though it's not actually the silicone going mouldy, its bacteria, soap and dirt sitting on top of the silicone which is the problem.

Mould can be best prevented, with a treatment with normal, household bleach at the first sign of discolouring, at least though every 6 weeks. (*WuduClean Mould Remover* is very effective)



Scratches

Scratches should not occur on the Wudumate if a respectful 'shoes off' policy is followed. If however scratches somehow occur, these can be removed in the same way as scratches are removed from the bodywork of motor cars, using T-Cut scratch removers, finished with liquid polish.

Once the WuduMate is free of grease/dirt/lime-scale, polish thoroughly with T-Cut, and/or a fine sandpaper - 600 grit or higher.

When the scratches have been removed, the original shine can be largely (if not fully) recreated by buffing/polishing with a dry cloth, or mechanized drill-based polisher/buffer.

Dripping Taps

Normally after several years of heavy use, sometimes caused by foreign bodies in the water, taps may drip. The WuduMate Wall Mounted Tap can easily be mended by changing the cartridge which does not involve removing the tap.

Specialist Washing Company Limited, PO Box 541, Egham, Surrey, TW20 0WN, UK
Trading as WuduMate®

Tel: +44 (0) 1784 748080

info@wudumate.com | www.wudumate.com

Registered in England No 6239360
Registered Office: 'Fifth Floor', 11 Leadenhall Street, London EC3V 1LP, UK